MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 44) at each scheduled maintenance period.

I : INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult your authorized Honda dealer.

	FREQUENCY		WHICHEVER -		ODOMETER READING (NOTE 1)							
		COMES FIRST	×1,000 km	1	6	12	18	24	30	36		
ITEM		ŧ	×1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTHS		6	12	18	24	30	36	Refer to page	
*	FUEL LINE					Ι		1		_		
*	THROTTLE OPERATION					I		1		_		
*	CARBURETOR CHOKE					1		1		1		
	AIR CLEANER	NOTE 2					R			R	73–74	
	SPARK PLUGS				_	R	_	R	1	R	75–76	
*	VALVE CLEARANCE			_				1				
	ENGINE OIL			R		R		R		R	70	
	ENGINE OIL FILTER			R		R		R		R	71	
*	CARBURETOR SYNCHRONIZATION			1		_		-		_		
*	CARBURETOR IDLE SPEED			1	_		-	-	_	_		
	RADIATOR COOLANT	NOTE 3						1		R	22-23	
*	COOLING SYSTEM					Ī		Ī		ı		
*	SECONDARY AIR SUPPLY SYSTEM	NOTE 4				Ī		Ī				
**	TIMING BELT			EVERY 100.000 km (60.000 mi) I								
				EVERY 150.000 km (90.000 mi) R								