


-
- **Position Light Maintenance Cover**
Remove the screws, then slide the cover to the rear.



- **Taillight Maintenance Cover**
Push the flaps of the document compartment in and back against the sides of the document compartment ①. Pull the rear of the document compartment up toward the front ②.

