

- 
- \* If a radio etc. is installed in the seat cowl, remove the rear cowl before replacing the bulb.

To remove:

- Remove the two bolts, then lift the rear cowl up.
- Unplug the connectors and remove the rear cowl.

