

## FEATURES (Not required for operation)

---


### HELMET HOLDERS

The helmet holders are under the seat.

Remove the seat (page 37). Hang your helmet(s) on the holder pin. Install the seat.

#### **▲ WARNING**

- ***The helmet holder is designed for helmet security while parked. Do not ride with a helmet attached to the holder; the helmet may interfere with safe operation and result in loss of control.***




### LUGGAGE TIE-DOWN HOOKS

Two Luggage tie-down hooks are located under the seat.

Remove the seat (page 37). Open the tie-down hooks and install the seat.

#### **CAUTION:**

- ***Never use the tie-down hooks to tow or lift the motorcycle.***



Luggage Tie-Down Hooks