
SADDLEBAGS

The saddlebags are for lightweight items. Do not carry more than 6.8 kg (15.0 lbs) in each saddlebag.

To Open the Saddlebags:

Install the ignition key and turn it clockwise. Pull the handle up to open the saddlebags.

To Lock the Saddlebags:

Close the saddlebags and handle. Turn the ignition key counterclockwise. Make sure the saddlebags are locked.

