

CONTENTS

SERIAL NUMBER LOCATION	5
CONTROL LOCATIONS	6
OPERATING INSTRUCTIONS	9
Speedometer	9
Main Switch	10
Ignition Switch.....	11
Headlight Switch.....	11
Turn Signal Switch.....	12
Horn Button	12
Document Compartment.....	12
Steering Lock	13
Helmet Holder	13
FUEL AND OIL	14
Fuel Valve	14
Choke Handle and Altitude Compensator Knob	15
Fuel Drain	16
Fuel Tank.....	17
Engine Oil Recommendation	18
Viscosity	18
PRE-RIDING INSPECTION	19
TIRE RECOMMENDATIONS	20