

Choke Knob

The choke knob (Fig. 2-6) is located above the ignition switch. The choke has three positions: full choke (A), half choke (B), and off (C).

Pulling the choke knob up (on) allows the carburetor to deliver a rich fuel mixture for starting the engine when cold. Lower the choke knob to the off position as the engine attains normal operating temperature.

To restart a warm engine, it is not necessary to use the choke.

CAUTION:

Extended use of the choke may impair piston and cylinder wall lubrication and shorten the life of the engine.




Fig. 2-6
(1) Choke knob

- (A) Full on position
- (B) Half on position
- (C) Off position