

DRAINING WATER FROM BRAKES

Make sure the engine is off and the parking brake is set. Then remove the drain bolt (Fig. 4-30) from the bottom of the rear brake cover. If any water drains, the brake seals must be replaced by your Honda dealer as soon as possible.




Fig. 4-30

(1) Rear brake drain bolt