

REVERSE SELECTOR KNOB AND REVERSE SEQUENCE

Reverse lever

The reverse selector knob (Fig. 2-13) (1) is near the clutch lever (2). The reverse lever (Fig. 2-13) (3) is above the left footpeg.

To shift into reverse, first bring the FOURTRAX to a complete stop and make sure the transmission is in neutral. While pushing the reverse selector knob (1) in, squeeze the clutch lever.

Pull up on the reverse lever and check that the reverse indicator lamp comes on.

CAUTION:

Bring the FOURTRAX to a complete stop before shifting the transmission into reverse. If the transmission is shifted into reverse while the vehicle is moving, the transmission will be damaged.




Fig. 2-13 (1) Reverse selector knob
(2) Clutch lever

(3) Reverse lever
(4) Reverse sequence