

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			92, 96
*	THROTTLE OPERATION		I	I	95
*	CARBURETOR CHOKE			I	100
	AIR CLEANER	(NOTE 1)		C	96–98
	AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	99
	SPARK PLUG			I	110, 111
*	VALVE CLEARANCE		I	I	111
	ENGINE OIL		R	R	32, 103–107
	ENGINE OIL FILTER		R	R	105–107
*	CARBURETOR IDLE SPEED		I	I	100–102
	FINAL DRIVE OIL	YEAR I, 2 YEARS R			108, 109
	BRAKE FLUID	(NOTE 3)		I	122, 123