

Refueling .....	84
Reserve fuel supply .....	27
<b>Fuses</b>	
Location .....	113
Replacement .....	113
<b>G</b>	
Gasoline (see Fuel)	
Gearshift pedal .....	23
Gearshifting .....	23, 59
Gear case oil .....	104
<b>H</b>	
Headlight switches .....	20
Helmet holder .....	29
High altitude carburetor adjustment .....	98
<b>Hills</b>	
Riding across slopes .....	74
Riding down hills .....	72
Riding up hills .....	65
Stopping on hills .....	67
Turning on slopes .....	75
<b>I</b>	
Idle speed adjustment .....	96
Ignition switch .....	13
<b>Indicator lamps</b>	
Neutral indicator lamp .....	22
Reverse indicator lamp .....	22
Inspection, pre-ride .....	36
<b>K</b>	
Kick starter .....	17
<b>L</b>	
<b>Loading</b>	
Loading guidelines and procedures .....	40
Weight limits .....	39
Lubrication (see Engine oil and Gear case oil)	