

## CONTENTS

|                                    | Page |
|------------------------------------|------|
| FOURTRAX SAFETY .....              | 1    |
| Special Safety Messages .....      | 1    |
| Warning Information .....          | 6    |
| PARTS LOCATION AND OPERATION ..... | 10   |
| Parts Location .....               | 10   |
| Parts Operation .....              | 13   |
| Power Controls .....               | 13   |
| Lights .....                       | 20   |
| Gearshift Controls .....           | 23   |
| Brake Controls .....               | 25   |
| Fuel Tank .....                    | 26   |
| Engine Oil .....                   | 28   |
| Additional Features .....          | 29   |
| RIDING YOUR FOURTRAX .....         | 34   |
| Before Riding .....                | 34   |
| Rider Preparation .....            | 34   |
| Vehicle Preparation .....          | 36   |
| Safe Riding Rules .....            | 44   |
| Riding .....                       | 56   |
| Starting the Engine .....          | 57   |
| Shifting Gears .....               | 61   |
| Riding in Reverse .....            | 62   |
| Making Turns .....                 | 64   |
| Riding Up Hills .....              | 67   |
| Riding Down Hills .....            | 74   |
| Crossing Slopes .....              | 76   |
| Making Turns on Slopes .....       | 77   |
| Riding Over Obstacles .....        | 78   |
| Riding Through Water .....         | 79   |
| Parking .....                      | 80   |

(cont'd)