LIGHTS

Headlight and Dimmer Switches

The headlight and dimmer switches (Fig. 2-12) are above the starter button, next to the gearshift switches.

Turning the headlight switch (1) ON ($\stackrel{*}{x}$) turns the headlight on. Use the dimmer switch (2) to select either high beam HI ($\stackrel{\equiv}{\mathbb{D}}$) or low beam LO ($\stackrel{\equiv}{\mathbb{D}}$) for the headlights.




Fig. 2-12 (1) Headlight switch (2) Dimmer switch