

Indicators & Display

1	Reverse indicator	Lights when the transmission is in reverse. <i>Lamp Check.</i>
2	Neutral indicator	Lights when the transmission is in neutral. <i>Lamp Check.</i>
3	Oil high temperature indicator	Lights when engine oil temperature is high enough to adversely affect the service life of the engine. If the oil high temperature indicator comes on while you are riding, immediately bring the vehicle to a stop, turn the engine off and let it cool. See page 180. <i>Lamp Check.</i>
4	Multi-function display	The display includes the following functions. <i>Display Check.</i>
	Gear position indicator	Show the gear position. (page 18)
	Speedometer	Shows riding speed.
	Odometer	Shows accumulated mileage (page 19).
	Tripmeter	Shows mileage per trip (page 19).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 20).
	Digital clock	Shows the time (hours and minutes) (page 21).
5	Odometer/tripmeter select button	Selects display of the odometer or tripmeter. Resets the tripmeter to zero (0) (page 20).
6	Hourmeter/digital clock select button	Selects display of the hourmeter or digital clock (pages 20 , 21).
7	Hour select button	Advances the hour displayed by the digital clock (page 21).
8	Minute select button	Advances the minutes displayed by the digital clock (page 21).