

# Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page	
		⇔	km	150	1000	2000		
			mi	100	600	1200		
		NOTE	HOURS	20	100	200		
*	FUEL LINE					I	—	
*	THROTTLE OPERATION					I	118	
*	CARBURETOR CHOKE					I	120	
	AIR CLEANER	NOTE 1				C	C	113
	AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	I	117
	SPARK PLUG					I	I	125
*	VALVE CLEARANCE			I	I	I	128	
	ENGINE OIL			R	R	R	105	
	ENGINE OIL FILTER			R	R	R	108	
*	ENGINE IDLE SPEED			I	I	I	123	

\* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.