

I	
Idle speed adjustment	104
Ignition switch	14
Indicator	
Neutral indicator.....	22
Oil high temperature indicator	22
Reverse indicator.....	22
Inspection, pre-ride	44
L	
Loading	
Loading guidelines and procedures.....	48
Weight limits.....	47
Lubrication	
(see Engine oil and Gear case oil)	
M	
Maintenance	
Precautions	92
Schedule	90
Modifications	52
Multi-function display (Canadian model only).....	24
N	
Neutral indicator	22
Noise emission control system.....	155
O	
Obstacles, riding over	86
Odometer (Canadian model only).....	28
Oil (see Engine oil and Gear case oil)	
Oil filler cap	106
Oil filter, changing.....	108
Oil high temperature indicator.....	22
Owner's manual compartment	39