

## MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Which ever comes first ⇒	INITIAL	REGULAR		Refer to page		
				MAINTENANCE	MAINTENANCE INTERVAL				
				mi	600	1200			
			km	1000	2000				
			NOTE	HOURS	20	100	200		
EMISSION RELATED ITEMS	*	FUEL LINE				I	—		
	*	THROTTLE OPERATION				I	98		
	*	CARBURETOR CHOKE				I	103		
		AIR CLEANER	(NOTE 1)			C	C	99 – 101	
		AIR CLEANER HOUSING	(NOTE 2)			I	I	102	
		DRAIN TUBE							
		SPARK PLUG				I	I	112 – 113	
	*	VALVE CLEARANCE				I	I	I	113
		ENGINE OIL				R	R	R	35, 106 – 110
		ENGINE OIL FILTER				R	R	R	108 – 110
	*	ENGINE IDLE SPEED				I	I	I	104

- I: Inspect and Clean, Adjust,  
Lubricate or Replace if necessary.  
C: Clean      R: Replace  
A: Adjust      L: Lubricate