

D

| | |
|---------------------|--------|
| Dimmer switch | 18 |
| Dipstick | 24, 94 |
| Drive chain | 101 |

E

| | |
|---|--------|
| Emission control system | 143 |
| Engine | |
| Idle speed adjustment | 91 |
| Break-in procedures | ii |
| Engine guard | 128 |
| Flooded engine | 58 |
| Starting the engine | 55 |
| Engine oil | |
| Changing oil | 97 |
| Checking oil level and adding oil | 94 |
| Oil filler cap/dipstick | 24, 94 |
| Recommendations | 96 |
| Engine stop switch | 14 |
| Exhaust system | |
| Cleaning | 35 |
| Purging | 130 |

F

| | |
|---|--------|
| Flag pole bracket | 29 |
| Flooded engine | 58 |
| Fuel | |
| Fuel recommendations | 84 |
| Fuel fill cap | 22, 82 |
| Fuel tank capacity | 82 |
| Fuel valve | 23 |
| High altitude fuel mixture adjustment | 92 |
| Refueling | 82 |
| Reserve fuel supply | 23 |
| Fuse | |
| Location | 113 |
| Replacement | 114 |