
Controls & Features

Choke Lever

LEFT SIDE



The choke lever may be used when starting the engine. See page 44.