


Brakes

Front Brake Fluid Level

With the ATV in an upright position, check the fluid level. It should be above the LOWER level mark (1). If the level is at or below the LOWER level mark, check the brake pads for wear (page 128).

Worn brake pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.

RIGHT HANDLEBAR



(1) LOWER level mark