

Other Inspection

- Make sure there are no fluid leaks.
- Check for deterioration or cracks in the hoses and fittings.
- The rear brake pedal pivot must be inspected according to the Maintenance Schedule.

See your Honda dealer for this service.