## Speedometer/Hourmeter

(Ref. No.) Description	Function
(1) Speedometer	Shows riding speed.
(2) Odometer	Shows accumulated mileage.
(3) Tripmeter	Shows mileage per trip.
(4) Tripmeter reset knob	Resets tripmeter to zero (0) by pushing the knob.
(5) Hourmeter	Shows hours and tenth of hours of engine operation. Operates when the ignition switch is turned I (ON). Provides accurate service period information for initial and regular maintenance.
(6) Hourmeter indicator	Blinks when the hourmeter is operating. Should blink when the ignition switch is turned I (ON).




Fig. 2-15