

I	
Idle speed adjustment	97
Ignition switch	14
Indicator lamp	
Neutral indicator lamp	23
Reverse indicator lamp	23
Inspection, pre-ride	38

L	
Loading	
Loading guidelines and procedures	42
Weight limits	41
Lubrication	
(see Engine oil, Gear case oil and differential oil)	

M	
Maintenance	
Precautions	85
Schedule	84
Modifications	46

N	
Neutral indicator lamp	23
Noise emission control system	152

O	
Obstacles, riding over	80
Oil (see Engine oil, Gear case oil and differential oil)	
Oil filler cap/dipstick	31, 100
Oil filter, changing	102
Owner's manual compartment	35