



0 8 / 0 5 / 0 6 1 7 : 0 9 : 5 4 3 1 H P 7 6 0 0 0 0 1 8



## Instruments & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations .....	11
Indicators & Displays.....	14
Multi-function Display.....	18
Gear Position Indicator.....	19
Oil Change Indicator .....	20
Odometer.....	21
Tripmeter.....	21
Hourmeter .....	22
Fuel Gauge .....	23



(cont'd)

