


Vehicle Identification

Serial Numbers

The VIN, engine serial number, and key number may be required when ordering replacement parts. You may record these numbers in the Quick Reference section at the rear of this manual.


The VIN (1) is stamped on the front of the frame.

FRONT



The engine number (2) is stamped on the upper side of the rear crankcase.

LEFT SIDE



(2) engine number

210 Technical Information

