

# Index

---

## D

differential oil (TRX420FM only) .....	116
dimmer switch, headlight .....	28
dipstick .....	109
display check .....	15
display, multi-function .....	18
driveshaft boots (TRX420FM only) .....	160
drivetrain boots .....	162

## E

engine,	
flooded .....	62
guard .....	157
number .....	202
oil .....	105
pinging .....	102
starting .....	60
stop switch .....	27
stopping .....	63
won't start .....	184
environment .....	180
exhaust system,	
cleaning .....	44
purge .....	138