

Maintenance Schedule

ITEMS		FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
			mi	km	100	600	1200	
					150	1000	2000	
			NOTE	HOURS	20	100	200	
NON EMISSION RELATED ITEMS		DRIVESHAFT BOOTS						150
		REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL				(R:EVERY 2 YEARS)		109
	*	BRAKE FLUID	NOTE 3					129
	*	BRAKE SHOE WEAR	NOTE 1					140
		BRAKE SYSTEM						129
	*	REVERSE LOCK SYSTEM						122
		SKID PLATES, ENGINE GUARD						149
	*	CLUTCH SYSTEM						121
	*	SUSPENSION						—
	*	SPARK ARRESTER				C	C	128
	*	NUTS, BOLTS, FASTENERS						—
	**	WHEELS/TIRES						142
	**	STEERING SHAFT HOLDER BEARINGS						—
**	STEERING SYSTEM						—	

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 204).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.