


Controls & Features

Kickstarter

RIGHT SIDE



(1) kickstarter

The kickstarter (1) is used to start the engine. To operate, swing the kickstarter out from its stored position and depress it through its entire stroke. See Starting Procedure, page 46 .