

CONTENTS

| | Page |
|-----------------------------------|------|
| FOURTRAX SAFETY | 1 |
| Special Safety Messages | 1 |
| Warning Information..... | 6 |
| PARTS LOCATION AND OPERATION..... | 10 |
| Parts Location | 10 |
| Parts Operation..... | 14 |
| Power Controls | 14 |
| Lights | 21 |
| Gearshift Controls..... | 29 |
| Brake Controls..... | 31 |
| Fuel Tank Controls | 32 |
| Engine Oil | 35 |
| Additional Features | 36 |
| RIDING YOUR FOURTRAX | 42 |
| Before Riding | 42 |
| Rider Preparation..... | 42 |
| Vehicle Preparation | 44 |
| Safe Riding Rules..... | 52 |
| Riding | 64 |
| Starting the Engine | 65 |
| Shifting Gears | 69 |
| Riding in Reverse..... | 70 |
| Making Turns | 72 |
| Riding Up Hills | 75 |
| Riding Down Hills | 82 |
| Crossing Slopes | 84 |
| Making Turns on Slopes..... | 85 |
| Riding Over Obstacles | 86 |
| Riding Through Water | 87 |
| Parking..... | 88 |

(cont'd)