

CONTENTS

	Page
MAINTENANCE AND REPAIRS	89
Emission Requirements	89
Maintenance Schedule	90
Maintenance Precautions	92
Tool Kit	93
Fuel System	94
Lubrication	106
Engine	114
Clutch	116
Electrical System	118
Brakes	125
Wheels and Tires	135
Seat Removal	140
Engine Guard and Skid Plates	141
Spark Arrester	142
Driveshaft Boots	144
TRANSPORTING YOUR FOURTRAX	146
CLEANING YOUR FOURTRAX	149
STORING YOUR FOURTRAX	151
SPECIFICATIONS	154
WIRING DIAGRAM	156
CONSUMER INFORMATION	157
WARRANTY SERVICE	159
SERIAL NUMBERS AND COLOR LABEL	160
INDEX	161
AUTHORIZED MANUALS	167