

Starting primer knob.....	18
Storage compartment.....	47
Storing procedures .....	165

## T

Throttle	
Cable .....	108
Lever.....	20, 108
Tires	
Inflation and air pressure .....	151
Repairing.....	154
Specifications .....	152
Tread condition .....	153
Tool kit .....	103
Trailer hitch .....	46
Trailer towing	
Operational guidelines.....	56
Weight limits.....	55
Transporting procedures.....	160
Tripmeter.....	29
Turning	
On level ground.....	82
On slopes .....	95

## V

Valve clearance .....	128
-----------------------	-----

## W

Warning labels .....	7
Warranty service.....	173
Water	
Draining from brakes .....	149
Riding through.....	97
Weight limits .....	55
Wheel removal.....	150
Wiring diagram .....	170