

## RIDING IN REVERSE

To shift into reverse, first bring the vehicle to a complete stop and make sure the transmission is in neutral. Then follow these procedures:

1. Depress and hold down the brake pedal.
2. Be sure there are no obstacles or people in the way.
3. While pushing the release button, shift the gearshift lever into "R" (Reverse) gear.
4. Release the rear brake pedal.
5. Open the throttle gradually and ride slowly. Do not open the throttle suddenly or make abrupt turns.
6. To stop, close the throttle and gradually apply both the front and rear brakes. Do not abruptly apply the rear brake by itself.
7. To shift out of reverse and into neutral, shift the gearshift lever into "N" (Neutral) gear.

### CAUTION:

**Bring the FOURTRAX to a complete stop before moving the shift lever. If the shift lever is moved while the vehicle is moving, the transmission may be damaged.**

While reading this manual, remember:

**▲WARNING** Indicates a strong possibility that serious injury or death may result if instructions are not followed.