



Indicators & Displays

(TRX500FA only)

- To zero the minute display, press and hold both the hour and minute buttons simultaneously for two seconds.



(1) hourmeter/digital clock
select button
mode select button
(TRX500FGA)

(2) hour select button
plus button (TRX500FGA)
(3) minute select button
minus button (TRX500FGA)

(TRX500FGA only)

- Your ATV's digital clock has an automatic adjustment function whenever the GPS mode is selected and the system's satellite status is 3D Navigation (page 70).