


System Start-up


System Failure to Display a Position Fix

If the receiver does not get a position fix within about 8 minutes (flashing antenna mark (1) as shown in the illustration), make sure there are no overhead obstructions (building, trees, canopy, etc.) and then perform the following:



(1) antenna mark

1. Turn the ignition switch OFF (O).
2. Remove the seat (page 138).
3. Remove the rear fender lid (page 199).
4. Disconnect the negative (-) terminal lead (2) from the battery (3) and wait for 1 minute.



(2) negative (-) terminal lead
(3) battery