

# Riding in Reverse

---

If you need to ride in reverse, make sure the area behind you is clear and only operate the ATV at low speed.

## **WARNING**

Improperly operating in reverse could cause you to hit an obstacle or person behind you, resulting in serious injury.

Make sure there are no obstacles or people behind you before selecting reverse gear. When it is safe to proceed, go slowly.

1. Bring the vehicle to a complete stop, then make sure the transmission is in neutral.
2. Depress and hold down the brake pedal.
3. Be sure there are no obstacles or people in the way.
4. While pushing the release button, shift the shift lever into “R” (Reverse) gear.

If the vehicle won't shift easily into reverse, rock the vehicle slightly while moving the lever toward the reverse position. This will help line up the gears in the sub-transmission.

## **NOTICE**

*If the shift lever is moved while the vehicle is moving, the sub-transmission may be damaged.*

5. Release the rear brake pedal.
6. Open the throttle gradually and ride slowly. Do not open the throttle suddenly or make abrupt turns.

(cont'd)