



0 8 / 0 3 / 1 8 1 8 : 2 5 : 2 4 3 1 H N 2 6 8 0 0 0 6 2



GPScape System (TRX500FGA/FPA)

This section explains the GPScape navigation system. Instructions for the topics listed on this page are included.

Introduction.....	54
Important Safety Information	57
System Limitations.....	58
System Start-up	59
Position Fix	59
System Failure to Display a Position Fix	60
Satellite Status.....	62
GPS Mode	64
GPS Mode Display.....	67
Waypoint Number Display	68
Direction to Waypoint Display	69
Distance to Waypoint.....	71
Basic Waypoint Selection	72
Advanced Waypoint Selection.....	76
Determining the Coordinates of Your Current Position.....	86
Compass Direction Indicator.....	87
Automatic Clock Adjustment.....	89

