

# Table of Contents

---

<b>BASIC OPERATION &amp; RIDING .....</b>	<b>57</b>
Safe Riding Precautions .....	59
Off-Road Use Only .....	59
Keeps Hands and Feet on Controls .....	60
Control Speed .....	61
Use Care on Unfamiliar or Rough Terrain .....	62
Do Not Perform Stunts .....	63
Starting & Stopping the Engine .....	64
Preparation .....	64
Starting Procedure .....	65
Flooded Engine .....	67
Stalled Engine .....	67
How to Stop the Engine .....	68
Using the Recoil Starter .....	69
Shifting Gears .....	70
Riding in Reverse .....	76
Braking .....	78
Riding Your ATV .....	80
Making Turns .....	80
Skidding or Sliding .....	82
Riding Up Hills .....	83
Riding Down Hills .....	87
Crossing or Turning on Hills or Slopes .....	88
Riding Over Obstacles .....	90
Riding Through Water .....	91
Parking .....	92

# Table of Contents

---

<u>Chassis</u>	
Brakes .....	145
Tyres .....	156
Engine Guard & Skid Plate .....	163
Driveshaft Boots .....	164
<u>Electrical</u>	
Battery .....	165
Appearance Care .....	170
<b>TIPS.....</b>	<b>175</b>
Preparing for a Ride .....	176
What to Take to The Riding Area .....	176
What to Take on The Trail .....	177
Transporting Your Honda .....	178
Storing Your Honda .....	180
You & the Environment .....	184
<b>TAKING CARE OF THE UNEXPECTED.....</b>	<b>185</b>
General Guidelines .....	186
If Your Engine Quits or Won't Start .....	188
If the Transmission Is Not Functioning Properly .....	191
If the Battery Is Dead .....	193
If You Have a Flat Tire .....	194
If the Oil/Coolant High Temperature Indicator Lights .....	197
If a Fuse Blows .....	199
If You Crash .....	202
If You Lose Your Key .....	203
If a Component Fails .....	204