Indicators & Displays


Fuel Gauge

The fuel gauge liquid crystal display (1) shows the approximate fuel supply available. The fuel tank capacity is:

4.49 US gal (17.0 l)

When segment RES (2) flashes, you should refill the tank as soon as possible. The amount of fuel remaining when the flashing starts is approximately:

1.08 US gal (4.1 l)



All segments will flash, when the fuel gauge function is fails. See your Honda dealer.

