



Indicators & Displays

7	Multi-function display	The display includes the following functions. <i>Display Check</i> .
	Drive mode indicator	Shows the driving mode (page 19).
	Gear position indicator	Shows the gear position (page 20).
	Speedometer	Shows riding speed.
	Fuel gauge	Shows approximate fuel supply available (page 26).
	Oil change indicator	Lights when specified maintenance interval for engine oil change is reached (page 21).
	Odometer	Shows accumulated mileage (page 22).
	Tripmeter	Shows mileage per trip (page 22).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 24).
	Digital clock	Shows the time (hours and minutes) (page 25).
8	Hour select button	Advances the hour displayed by the digital clock (page 25).
9	Minute select button	Advances the minutes displayed by the digital clock (page 25).
10	ADJ button	Used to set the digital clock (page 25).
11	PGM-FI indicator	Lights when there is any abnormality in the PGM-FI (Programmed Fuel Injection) system. Should also light for a few seconds and then go off when the ignition switch is turned ON and use the start button. If the indicator comes on at any other time, reduce speed and take your vehicle to a Honda dealer as soon as possible. <i>Lamp Check</i> .

