

Is Your ATV Ready to Ride?

If you are carrying cargo, also check the following:

Loading Limits	Make sure you do not exceed the load limits (page 54).
Cargo	Check that all cargo is secure.
Check these items after you get on the ATV:	
Throttle	Check the freeplay and adjust if needed. Press the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions (page 136).
Brakes	Squeeze the front and rear brake levers and step on the rear brake pedal to check that the controls operate normally. Press down on the rear brake pedal several times, then check for proper brake lever freeplay (page 149). Make sure there is no brake fluid leakage.



