

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ↷	INITIAL MAINTENANCE		REGULAR MAINTENANCE INTERVAL		Refer to page
				mi	100	600	1200	
				km	150	1000	2000	
				NOTE	HOURS	20	100	
EMISSION RELATED ITEMS	*	FUEL LINE				I	—	
	*	THROTTLE OPERATION				I	120,121	
		AIR CLEANER	(NOTE 1)			C	C	122 – 124
		SPARK PLUG				I	I	136,137
	*	VALVE CLEARANCE			I	I	I	137
		ENGINE OIL			R	R	R	40,41 128 – 131
	**	ENGINE OIL STRAINER SCREEN					C	—
	**	ENGINE OIL CENTRIFUGAL FILTER					C	—
	*	ENGINE IDLE SPEED			I	I	I	126
	*	SECONDARY AIR SUPPLY SYSTEM					I	—

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate