

- Gently wash the air cleaner and sub air clener in clean, non-flammable (high flash point) solvent such as kerosene—not gasoline.
Allow the air clener to dry thoroughly before applying oil. A wet air cleaner will not fully absorb the oil.

⚠ WARNING

POTENTIAL HAZARD

Using gasoline or low flash point solvents for cleaning ATV parts.

WHAT CAN HAPPEN

A fire or explosion could result.

HOW TO AVOID THE HAZARD

Use only a nonflammable or high flash point solvent to clean ATV parts.

- Soak the air cleaner in Pro Honda Foam Filter Oil or an equivalent until saturated, then squeeze out the excess oil.

CAUTION:

Twisting the air cleaner when squeezing out excess oil could damage the air cleaner.

- Reassemble by reversing the disassembly sequence.