

Is Your ATV Ready to Ride?

Pre-ride Inspection

Check the following items before you get on the ATV:

- | | |
|---------------------------------------|--|
| <i>Engine Oil</i> | Check the level and add oil if needed (page 100).
Check for leaks. |
| <i>Fuel</i> | Check the level and add fuel (page 97) if needed. Also make sure the fuel fill cap is securely fastened.
Check for leaks. |
| <i>Tires</i> | Use a gauge to check the air pressure. Adjust if needed. Also look for signs of damage or excessive wear (page 126). |
| <i>Drive Chain</i> | Check the condition and slack. Adjust and lubricate if needed (page 135). |
| <i>Nuts & Bolts</i> | Check the wheels to see that the axle nuts are tightened. Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight. |
| <i>Underbody & Exhaust System</i> | Check for, and remove, any dirt, vegetation or other debris that could be a fire hazard or interfere with the proper operation of the vehicle. |