

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		⇔	mi	100	600	1200	
			km	150	1000	2000	
		NOTE	HOURS	20	100	200	
DRIVE CHAIN		NOTE 1, NOTE 3		I, L	I, L EVERY 300mi (500km) or 50 operating hours!		134
DRIVE CHAIN SLIDER							136
* BRAKE SHOE WEAR		NOTE 1					124
BRAKE SYSTEM							118
SKID PLATES							133
* CLUTCH SYSTEM							111
* SUSPENSION							—
* SPARK ARRESTER					C	C	117
* NUTS, BOLTS, FASTENERS							—
** WHEELS/TIRES							—
** STEERING SHAFT HOLDER BEARINGS							—
** STEERING SYSTEM							—

- * Should be serviced by your Honda dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 192).
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.