

## Engine Oil

---

3. Pour the drained oil into a suitable container and dispose of it in an approved manner (page 170).

### NOTICE

*Improper disposal of drained fluids is harmful to the environment.*

#### *Add Engine Oil:*

1. Reinstall the oil drain plug with a new sealing washer, and tighten it to the specified torque:  
**24 N·m (2.4 kgf·m , 17 lbf·ft)**
2. Fill the crankcase with the recommended grade oil approximately:  
**0.7 ℓ (0.7 US qt , 0.6 Imp qt)**
3. Reinstall the oil fill cap/dipstick.
4. Start the engine and let it idle for 3 – 5 minutes.
5. Stop the engine and check the oil level. Make sure the oil is between the upper and lower level marks on the oil fill cap/dipstick. If necessary, add more oil but do not overfill.
6. Check that there are no oil leaks.

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly.