

Tires – Check the air pressure and the tires for wear or damage.

Battery electrolyte – Check the level and add if necessary.

Throttle operation – Check throttle operation, cable routing and free play.

Correct or replace if necessary.

Lighting – See if all lights operate properly.

Drive chain – Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry. Replace if it is badly worn or damaged.

Pneus – Vérifier la pression des pneus et l'état d'usure ou dommage des mêmes.

Electrolyte de la batterie – Vérifier le niveau et ajouter, si nécessaire.

Fonctionnement de la poignée des gaz – Vérifier le bon état de fonctionnement de la poignée des gaz, pose des câbles, et jeu libre. Régler ou remplacer, si nécessaire.

Eclairage – S'assurer que tous les feux fonctionnent correctement.

Chaîne de transmission – Mesurer le jeu; la dureté d'articulation due à une lubrification négligée ou autres conditions essentielles à la bonne conduite.