


Instruments (Continued)



FCD button

TOTAL/TRIP button

Air temperature gauge (AIR)

Display range: -10 to 50 °C

- Below -11 °C: " - - " displays
- Above 50 °C:

▶ - Air temperature gauge (flashing digits)
 ▶ The temperature readout may be incorrect at low speeds due to reflected heat.

Clock (12-hour display)

To set the clock **↔ P.24**