


### **CAUTION:**

- \* Removing the battery caps can damage the caps and result in leaks and eventual battery damage.
- \* When the motorcycle is to be stored for an extended period of time, remove the battery from the motorcycle and charge it fully. Then store it in a cool, dry place. If the battery is to be left in the motorcycle, disconnect the negative cable from the battery terminal.

### **Battery Removal**

1. Remove the seat (page 40).
2. Remove the band (1).
3. Remove the battery cover (2).



(1) Band