

<b>(Ref.No.) Description</b>	<b>Function</b>
(1) Speedometer	Shows riding speed.
(2) Odometer	Shows accumulated mileage.
(3) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(4) Side stand indicator (amber)	Lights when the side stand is put down. Before parking, check that the side stand is fully down; the light only indicates the side stand ignition cut-off system (page 78) is activated.
(5) High beam indicator (blue)	Lights when the headlight is on high beam.
(6) Digital clock	Shows hour and minute (page 15).
(7) Tachometer	Shows engine rpm.
(8) Tachometer red zone	<p>Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.</p> <p><b>CAUTION:</b></p> <p><b>* Running the engine beyond recommended maximum engine speed (tachometer red zone) can damage the engine.</b></p>
(9) Fuel indicator	<p>Lights when there is only few fuel left in the tank.</p> <p>about :</p> <p>3.3 ℓ (0.87 US gal , 0.73 Imp gal)</p>