

(Ref.No.) Description	Function
(8) RESET button	This button is used to reset the tripmeter or to select the tripmeter or odometer or to adjust the time.
(9) HISS button	This button is used to cancel flashing the immobilizer system (HISS) indicator when the ignition switch is OFF (page 52).
(10) Immobilizer system (HISS) indicator (red)	This indicator lights for a few seconds when the ignition switch is turned ON and the engine stop switch is at ○ (RUN). It will then go off if the properly-coded key has been inserted. If an improperly-coded key has been inserted, the indicator will remain on and the engine will not start (page 51).